

Servery Sash Lift

Installation Instruction

Usage: This instruction is relevant for Ultimate Awning Pushout Servery (UAWNPOSERV) and Ultimate Wood Awning Pushout Servery (UWAWN-POSERV) manufactured January 2022 to present.

STANDARD PARTS SHIPPED

- Sash Lift
- 2- #8 x 1" slotted oval head wood screws

YOU WILL NEED TO SUPPLY

- Pencil and tape
- Awl or marker point
- Drill and 3/32" drill bit
- Straight blade screwdriver.

Installation Procedures

1. Determine desired center(s) of sash lift across bottom rail. Mark location near top of flat face with tape and pencil.

2. Cut out template (**found on the reverse side**) and position on the bottom rail. Align the template along the top edge of rail face (aligned with the daylight opening (DLO)). Mark screw holes with an awl or pencil. The holes should be a minimum of 3/4" from the DLO.

3. Drill pilot holes at screw locations with a 3/32" drill bit 3/4" - 1" (22-25) deep.

4. Position the handle on the rail, and attach with screws using a straight blade screwdriver. Remove tape and pencil marks used to locate.

IMPORTANT

Print template at a 1:1 ratio (no scaling). After printing, check the measurement on the template for accuracy.

